

Technical overview.

SURE 500

	Basic data						Microphone system				Signal processing (one step)						Signal transmission/ binaural hearing		Details								Remote control					
	Performance data (2 cc coupler)	Battery size	Number of channels (G/AGC)	Number of microphones	Number of programs	Connection to the computer	Automatic/Natural Sound	Dir. adaptive	Dir.	Omni	DataLogging	Acclimatisation Manager	Voice Detection	Noise Reduction	Sound Impulse Management	Active Wind Block	Active Feedback Block	Situation Optimizer	Bluetooth functionality	i-com2	Multimic	PhoneConnect	Contactmatic	Volume control (VC)	Program pushbutton	Telephone Coil	Audio input/audio adapter FM (voice-activated) Selection: A MA A/MA/M	Child earhook	Battery compartment lock	Media (Bluetooth)	eMote2	
X-Mini	108/45 119/55 122/65	312	8/8	2	4	Prog. adapter	•	•	•	•	•	•	•	•	•	•	•		•	•					•							•
Mini	124/40	312	8/8	2	4	Prog. adapter	•	•	•	•	•	•	•	•	•	•	•		•	•												•
Slim	125/58	312	8/8	2	4	Prog. socket	•	•	•	•	•	•	•	•	•	•	•		•	•			•	•	•			•				•
Power	130/70	13	8/8	2	4	Prog. socket	•	•	•	•	•	•	•	•	•	•	•		•	•	•		•	•	•	•	•	•	•	•	•	•
CIC	115/35 115/40 115/45	10	8/8	1	4	Flex Connect				•	•	•	•			•			•					•								•
Mini-Canal	115/40 120/45	10	8/8	2	4	Flex Connect	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•	•	•	•							•
Canal	120/45 120/50	312	8/8	2	4	Flex Connect	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•	•	•	•							•
Concha	125/50 125/55 125/60	13	8/8	2	4	Flex Connect	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•	•	•	•							•